



7-Day Digital Heavy Duty Grounded Timer Instructions

SETTING THE TIME

1. Press "CLOCK" and "HOUR" at the same time to set the hour.
 2. Press "CLOCK" and "MIN" at the same time to set the minutes.
 3. Press "CLOCK" and "WEEK" at the same time to set the week.
-

SETTING THE TIMER PROGRAM

1. Press "PROG" to enter into the setting mode. The display shows "1 ON".
2. Press "HOUR", "MIN" and "WEEK" to set the hour and minutes as well as the day of the week for the timer on.
3. Press "PROG" again to set the off time. The display will show "1 OFF".
4. Repeat step 2 to set the off time.
5. Press "PROG" again to enter into the second on/off mode.
6. Repeat steps 1 through 4 to set the timer on/off.

There are a total of eight groups of timer settings. In the time setting mode, press "R" for canceling the setting time. Press the "R" again to return to the previous set time.

COMBINATION WEEKLY SETTINGS

1. In the timer on/off setting mode, press "WEEK" once. The display will show "Mo, Tu, We, Th, Fr, Sa, Su". This means it is a daily on/off setting.
 2. Press "WEEK" again, the weekday will show. Set to the required weekday. In this setting the timer will only work on the set weekday.
 3. After the display showing Su, the next press will show "Mo, Tu, We, Th, Fr". The timer only shows the settings for the selected days in the week.
-

NOTE: If the timer is set to "ON", it must first be set to "OFF" before it can be switched to "AUTO".

TROUBLESHOOTING

Problem: I plugged the timer in, and the display is blank or not changing when I press any of the buttons.

Solution: The timer has a rechargeable battery which saves your programs if the power goes out. It needs to be charged before the timer will operate properly. Plug the timer in for 20 to 30 minutes before programming. After that time period, take a pen or pencil and push in the little round reset button to the right of the ON/AUTO/OFF button. Then cycle through the ON/AUTO/OFF BUTTON. The light should come on in the ON position and off in the OFF position. Set the clock then your program. Press the CLOCK button when done programming. Now press the ON/AUTO/OFF button until it says ON, and the light comes on. Now press it one more time to put it in the AUTO position. The light should stay on if current time displayed is in-between the start and stop settings for your program.

